Interior lights list

1 Front personal lights (→P. 209)
2 Front interior light (→P. 209)
3 Front overhead courtesy light
4 Rear personal lights (→P. 209)
5 Rear interior light
6 Rear overhead courtesy light
7 Shift lever lighting (when engine switch is in ACC or IG-ON mode)
8 Front foot well lighting
9 Front door courtesy lighting
10 Front scuff lighting (if equipped)
11 Outer foot lights

Turning the instrument panel light control knob fully to the left disables the shift lever lighting and front foot well lighting.

Illuminated entry system

The following interior lights come on automatically when you approach the vehicle with the electronic key on your person. Note that the illuminated entry system operates only when the interior light switch (door position ON/OFF) is ON.

- Front overhead courtesy light
- Rear overhead courtesy light
- Outer foot light

The following lights turn on when any of the doors is unlocked or opened.

- Front interior light
- Rear interior lights
- Front foot well lighting
- Front door courtesy lighting
- Front scuff lighting

The following lights turn on for approximately 15 seconds when the engine switch is turned to OFF from the IG-ON or ACC mode. (The lights turn off immediately if the doors are locked or the engine switch is set to ACC or IG-ON mode.)

- Front overhead courtesy light
- Rear overhead courtesy light

To prevent the battery from being discharged

If the overhead courtesy lights and interior lights remain ON when the door is not fully closed and the interior light switch (door position ON/OFF) is ON, the lights will go off automatically after 20 minutes.

Customization

Setting (e.g. The time elapsed before lights turn off) can be changed. (→P. 400)

Interior lights

1 Door position ON/OFF

2 ON/OFF

▶ Models without an electric moon roof

▶ Models with an electric moon roof

Personal lights

1 ON/OFF

▶ Front (models without an electric moon roof)

▶ Front (models with an electric moon roof)

▶ Rear